



INSTRUCTIONS FOR USING AND SETTING THE TELADROP RESETTABLE IMPACT INDICATOR

Each TelaDrop is provided with a carton warning label and a bill of lading label to be used as a system for monitoring your product during transit. We suggest the bill of lading label be placed on the bill of lading to notify the carrier or consignee that the shipment contains an impact monitor. The warning label should be placed on the top or side of the package. The TelaDrop may be placed on the inside or the outside of the package or on the product.

MOUNTING

Mount the TelaDrop with either adhesive back tape or two No. 6-32 screws. There is pressure-sensitive tape on the back of the indicator. Remove the liner from the tape and press the unit to a flat surface on the package or on the product to be monitored. The TelaDrop impact indicator must be aligned with the arrows pointed toward the direction of shock to be monitored. Three units are needed to provide complete three-dimensional readout (six directions).

TO ACTIVATE THE RESETTABLE TELADROP

A small 1/16-inch hole is provided in the center of each end of the plastic housing for the purpose of activating and resetting the unit. This hole is on the side of the case. A small paper clip with one end bent out can be used for activating and resetting the unit. Push the wire end of the paper clip into the small hole until the arrow snaps back into hiding and the spring is reset. Apply only enough force to reset the arrow and spring assembly. The arrow will snap quickly into a covered position and a slight snap can be heard. The impact indicator is now ready to use.